

Date d'édition : 12.06.2026

Ref : 4746421

Dénudeuse, réglable



Before the fibre can be used it has to be prepared in such a way that the input as well as output faces are perpendicular as well as of best optical quality. This is achieved by using a fibre cleaver and breaker. To do so first of all the plastic coating has to be removed by means of the so called Miller's pliers. The pliers have to be adjusted in such a way that the closed pliers do not scratch the glass of the fibre by removing the plastic cover. This is done by adjusting the diameter set screw.